




Item	Part #	Description
1	900033	3/4" eye bolt
2	900015	3/4" x 8" bolt with washer and lock nut
3	900029	Short beam clamp
3	900030	Long beam clamp (not shown in diagram)
4	900056	Parallel link bolt and bushing assembly (8 per row)
5	900057	.468" OT Ext. Hook on end down pressure spring
6	900013	Bottom stabilizer arms
7	900012	Top stabilizer arms
8	900053	Down pressure adjustment comb
9	900058	Down pressure adjustment slider hold down (right)
10	900059	Spring
11	900050	Bolt with washer, bushing and lock nut (assy)
12	900052	Upper adjustment handle (down pressure)
13	900055	Down pressure spring bolt
14	900051	Lower adjustment handle (down pressure)




Item	Part #	Description
1	900001	1/2" x 3-1/2" bolt with nut
2	900002	3/4" OD spacer/bushing
3	900003	Depth control handle spring
4	900004	Depth control handle
5	900021	Depth control cam
6	900022	3/4" nut (half width, locking)
7	900023	Spacer
8	900024	4" x 12" press/gauge wheel
9	900025	Gauge/press wheel arm
10	900027	5/8" x 4-1/2" bolt with nut and lock washer




Item	Part #	Description
1	900012	Row frame spacer (4 per row)
2	900028	Inside disc scraper (right side)
3	900014	Seed disc mounting plate
4	900018	Disc opener front guard
5	900013	Holding strap spacer
6	900016	Row frame, right side
7	900006	Row frame, left side
8	900038	Inside disc scraper (left side)



Item	Part #	Description
1	900015	15" disc opener
5	900005	5/16" x 3/4" bolt
7	900007	Soil scraper
8	900008	1/2" x 3/4" bolt with flat washer and lock nut
9	900009	Seed disc mounting bolt (right)
10	900010	Soil scraper mounting bracket (right)
11	900011	Soil scraper holding strap



Item	Part #	Description
1	900015	15" disc opener (set)
2	900017	3/4" x 3-1/2" bolt with lock nut
3	900001	1/2" x 3-1/2" bolt with lock nut
6	900006	Row frame, left side



Item	Part #	Description
1	900041	3/4" wavy coultter
2	900045	Coultter hub assembly (comes with bearing and snap ring)
3	900043	Bearing for coultter hub
4	900046	Step washer (2 per coultter)
	900040	Spacer assembly (not shown in drawing)
6	900047	5/8" x 5-1/2" bolt with lock nut
	900044	Snap ring for coultter hub (not shown in drawing)

